

















CONTROL COMPONENTS 控制開關

EXTENDED ILLUMINATED PUSHBUTTON TRANSFORMER			MUSHROOM HEAD 40mm PUSHBUTTON			MUSHROOM HEAD 40mm NEON LAMP			MUSHROOM HEAD 40mm TRANSFORMER		
											
											
φ 22	φ 25	φ 30	φ 22	φ 25	φ 30	φ 22	φ 25	φ 30	φ 22	φ 25	φ 30
			CA22-PM10	CA25-PM10	CA30-PM10						
			CA22-PM01	CA25-PM01	CA30-PM01						
CA22-PE11T	CA25-EP11T	CA30-PE11T	CA22-PM11	CA25-PM11	CA30-PM11	CA22-PM11N	CA25-PM11N	CA30-PM11N	CA22-PM11T	CA25-PM11T	CA30-PM11T

KNOB SELECTOR SWITCH 2 POSITION			KNOB SELECTOR SWITCH 2 POSITION NEON LAMP			KNOB SELECTOR SWITCH 2 POSITION TRANSFORMER			CONTACT BLOCK		
											
									CONTACT BLOCK		
φ 22	φ 25	φ 30	φ 22	φ 25	φ 30	φ 22	φ 25	φ 30			
CA22-SS210	CA25-SS210	CA30-SS210									
CA22-SS201	CA25-SS201	CA30-SS201									
CA22-SS211	CA25-SS211	CA30-SS211	CA22-SS211N	CA25-SS211N	CA30-SS211N	CA22-SS211T	CA25-SS211T	CA30-SS211T			